

ig-ann hars


















December 11, 2003

maintaining the data needed, and c including suggestions for reducing	lection of information is estimated to completing and reviewing the collect this burden, to Washington Headqu uld be aware that notwithstanding ar DMB control number.	ion of information. Send comments arters Services, Directorate for Info	regarding this burden estimate rmation Operations and Reports	or any other aspect of the property of the pro	his collection of information, Highway, Suite 1204, Arlington
1. REPORT DATE 11 DEC 2003		2. REPORT TYPE N/A		3. DATES COVE	ERED
4. TITLE AND SUBTITLE				5a. CONTRACT	NUMBER
LMT - Critical Design Review Ring Panels 1 - 4			5b. GRANT NUMBER		
			5c. PROGRAM ELEMENT NUMBER		
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
Composite Optics,	ZATION NAME(S) AND AD Inc an Alliant Teo ie San Diego, Califo	chsystems Affiliate 9	9617	8. PERFORMING REPORT NUMB	G ORGANIZATION ER
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)			10. SPONSOR/MONITOR'S ACRONYM(S)		
			11. SPONSOR/MONITOR'S REPORT NUMBER(S)		
12. DISTRIBUTION/AVAIL Approved for publ	LABILITY STATEMENT ic release, distributi	on unlimited			
13. SUPPLEMENTARY NO See also ADM0017	otes 73, Large Millimete	r Telescope Project	. , The original do	ocument cont	tains color images.
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFIC	CATION OF:		17. LIMITATION OF	18. NUMBER	19a. NAME OF
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	- ABSTRACT UU	OF PAGES 28	RESPONSIBLE PERSON

Report Documentation Page

Form Approved OMB No. 0704-0188

Agenda

	Introductions	8:00 – 8	3:15
•		0.00	






Rings 1-4 Design Presentation Outline


- Interface Control Drawings
- Design Similarities to Ring 5
- Top assembly views
- **♦** Truss Clearances
- Mass Summary
- Configuration Status





- ♦ Ring 1 ICD COI Dwg # 1616391 Rev -
 - » Referenced MAN Drawings Which Provided Panel Dimensions
 - » Interfaces Agreed and Locked at Rev (08/13/03)
 - » Satisfies Dimensional and Interface Requirements











- ◆ Ring 2 ICD COI Dwg # 1616392 Rev A
 - » Referenced MAN Drawings Which Provided Panel Dimensions
 - » Interfaces Agreed and Locked at Rev (08/13/03)
 - » Satisfies Dimensional and Interface Requirements











- Ring 3 ICD COI Dwg # 1616393 Rev -
 - » Referenced MAN Drawings Which Provided Panel Dimensions
 - » Interfaces Agreed and Locked at Rev (11/04/03)
 - » Satisfies Dimensional and Interface Requirements













- ◆ Ring 4 ICD COI Dwg # 1616394 Rev A
 - » Referenced MAN Drawings Which Provided Panel Dimensions
 - » Interfaces Agreed and Locked at Rev A (11/04/03)
 - » Satisfies Dimensional and Interface Requirements












Design Similarities with Ring 5

- Same axial and lateral fittings
- Same overall rib and cap geometry
- Same materials used in reaction structures and membranes
- Panel adjusters are same design:
 - » Ring 1: 176 adjusters per panel
 - » Ring 2: 174 adjusters per panel
 - » Ring 3: 142 adjusters per panel
 - » Ring 4 Generic: 182 adjusters per panel
 - » Ring 4 Tetrapod: 177 adjusters per panel






Reaction Structure Components








Ring 1 Top Assembly








Ring 2 Top Assembly








Ring 3 Top Assembly







Ring 4 Generic Top Assembly






Adjusters Omitted for Clarity



Ring 4 Tetrapod Top Assembly








Ring 1 Truss Clearances

- Values are the closest clearance to truss
 - » Parts modeled from nominal truss and panel dimensions









Ring 2 Truss Clearances

- ♦ Values are the closest clearance to truss
 - » Parts modeled from nominal truss and panel dimensions









Ring 3 Truss Clearances

- Values are the closest clearance to truss
 - » Parts modeled from nominal truss and panel dimensions










Ring 4 Truss Clearances near Tetrapod (worst case)


- Values are the closest clearance to truss
 - » Parts modeled from nominal truss and panel dimensions





Ring 4 Truss Clearances near Tetrapod Cont. (worst case)

- Values are the closest clearance to truss
 - » Parts modeled from nominal truss and panel dimensions



Front view showing diagonal truss tube





Ring 1 Mass Summary

ODIT DOOISH MAGO
117 kg. (257 lbs.)
8.4 kg. (18.6 lbs.)
3.8 kg. (8.4 lbs.)
33 kg. (72 lbs.)
4.5 kg. (10 lbs.)
132 kg. (292 lbs.)
299 kg. (658 lbs.)
11.86 m2
25.2 kg./m2
<=30 kg./m2





Ring 2 Mass Summary

Panel Membrane	127 kg. (281 lbs.)
Fittings	
Lateral	10.6 kg. (23.3 lbs.)
Axial	3.8 kg. (8.4 lbs.)
Adjusters	32 kg. (71 lbs.)
Fasteners + Reinforcements	4.5 kg. (10 lbs.)
Reaction Structure Ribs / Caps / Dia.	129 kg. (284 lbs.)
Total	307 kg. (677.7 lbs.)
Membrane Area	12.96 m2
Weight / Area	23.7 kg./m2
Requirement	<=30 kg./m2





Ring 3 Mass Summary

Panel Membrane	88.9 kg. (196 lbs.)
Fittings	
Lateral	10.6 kg. (23.3 lbs.)
Axial	1.9 kg. (4.18 lbs.)
Adjusters	26 kg. (58 lbs.)
Fasteners + Reinforcements	4.5 kg. (10 lbs.)
Reaction Structure Ribs / Caps / Dia.	116 kg. (255 lbs.)
Total	248 kg. (546 lbs.)
Membrane Area	9.20 m2
Weight / Area	26.9 kg./m2
Requirement	<=30 kg./m2





Ring 4 GENERIC Mass Summary

Panel Membrane	121 kg. (267 lbs.)
Fittings	
Lateral	8.4 kg. (18.6 lbs.)
Axial	1.9 kg. (4.2 lbs.)
Adjusters	33.5 kg. (74 lbs.)
Fasteners + Reinforcements	4.5 kg. (10 lbs.)
Reaction Structure Ribs / Caps / Dia.	142 kg. (314 lbs.)
Total	312 kg. (688 lbs.)
Membrane Area	12.32 m2
Weight / Area	25.3 kg./m2
Requirement	<=30 kg./m2





Ring 1 Configuration Management

Drawing number	Description	Rev. level
1615301	Panel Assy	-
1615311	Reaction Structure Assy	Α
1615501	Panel Adjuster	D
1615505	Lateral Fitting	Α
1615515	Axial Fitting	Α
1615525	Lateral Fitting	Α
1615N801	Rib NC File	-
1615N811	Cap NC File	-
1615N821	Cap NC File	-
1615391	Ring 1 ICD	-
1615401	Membrane	Α
Tooling		
1615101-1PDMO	Mold Assy	Not Rel
1615201	Assembly Fixture	Not Rel
1458101 PDMO	Mold Membrane	В
1458221	Panel Trim Tool	_
1615500	PDMO Adjuster	F





Ring 2 Configuration Management

Drawing number	Description	Rev. level
1615302	Panel Assy	-
1615312	Reaction Structure Assy	Α
1615501	Panel Adjuster	D
1615505	Lateral Fitting	Α
1615522	Lateral Fitting Ring 2	-
1615515	Axial Fitting	Α
1615N802	Rib NC File	-
1615N812	Cap NC File	-
1615N822	Cap NC File	-
1615392	Ring 2 ICD	Α
1615402	Membrane	Α
Tooling		
1615102-1PDMO	Mold Assy	Not Rel
1615202	Assembly Fixture	Not Rel
1458102 PDMO	Mold Membrane	В
1458222	Panel Trim Tool	-
1615500	PDMO Adjuster	F





Ring 3 Configuration Management

Drawing number	Description	Rev. level
1615303	Panel Assy	-
1615313	Reaction Structure Assy	-
1615501	Panel Adjuster	D
1615505	Lateral Fitting	Α
1615523	Lateral Fitting Ring 3	-
1615515	Axial Fitting	Α
1615N803	Rib NC File	-
1615N813	Cap NC File	-
1615N823	Cap NC File	-
1615393	Ring 3 ICD	-
1615403	Membrane	Α
Tooling		
1615103-1PDMO	Mold Assy	Not Rel
1615203	Assembly Fixture	Not Rel
1458103 PDMO	Mold Membrane	С
1458223	Panel Trim Tool	-
1615500	PDMO Adjuster	F





Ring 4 Configuration Management

Drawing number	Description	Rev. level
1615304	Panel Assy	-
1615314	Reaction Structure Assy	-
1615501	Panel Adjuster	D
1615505	Lateral Fitting	Α
1615525	Lateral Fitting	-
1615515	Axial Fitting	Α
1615N804	Rib NC File	-
1615N814	Cap NC File	-
1615N824	Cap NC File	-
1615394	Ring 4 ICD	Α
1615404	Membrane	Α
Tooling		
1615104-1PDMO	Mold Assy	Not Rel
1615204	Assembly Fixture	Not Rel
1458104 PDMO	Mold Membrane	В
1458224	Panel Trim Tool	-
1615500	PDMO Adjuster	F





Rings 1-4 Analysis Presentation



